

NOTE: Faux Cast Iron is for serving and display use only. Not intended for cooking.

ILLOGICAL

Make a solid, faux cast iron appearance indoors or out.



MFP5

Faux Cast Iron Fry Pan
5" dia. x 1 1/2" h.,
3 1/4" Handle



MFP6

Faux Cast Iron Fry Pan
6" dia. x 1 1/2" h.,
3 1/4" Handle



MFP8

Faux Cast Iron Fry Pan
8" dia. x 1 1/2" h.,
3 1/4" Handle



MFP10

Faux Cast Iron Fry Pan
10" dia. x 1 7/8" h.,
4 1/8" Handle



MFP14

Faux Cast Iron Fry Pan
12" dia. x 2" h.,
5" Handle



MGP13 - Faux Cast Iron Skillet
13" x 10 1/2" x 1 7/8" h.
w/ 1 1/2" Double Sided Handles



MFP85OV - Oval Faux Cast Iron Skillet
8 1/2" x 5 3/4" x 1 1/2" h.
w/ Handles



MFP1075 - Faux Cast Iron Fry Pan
10 3/4" dia. x 1 1/2" h., w/ 3 7/8" handle., Black
(No Feet) *Can be used as a charger plate.



MFP55 - Faux Cast Iron Fry Pan
5 3/8" sq. x 1" h., w/ 5" Handle



JW4 - Ramekin Sauce Bowl
4" dia. x 1 1/2" h., 5 oz.
(Only Available in Black)



JW322 - 3 Slot Zig Zag
6 1/2" x 5 1/8" x 2 1/4" h.
(Also Available in White)



RFP-2 - Ramekin Frying Pan
2 3/4" dia. x 1" h., 2 oz.



RFP-4 - Ramekin Frying Pan
3 1/2" dia. x 1 1/4" h., 4 oz.



RFP-6 - Ramekin Frying Pan
4" dia. x 1 1/2" h., 6 oz.

BLACK (B)